
CALPHA

40/45 DCOE & 40/45 Dellorto Throttle Postion Sensor Mounting Kit 9990266000 & 9990290200

- Remove the shaft nut and lock tab from the right hand side of the carburettor.
- 2. Fit the forked throttle lever in the orientation as shown in Fig.2. Refit the original lock tab and shaft nut.
- 3. Fit the throttle position sensor (TPS) mounting bracket in position and secure with two M5 mounting screws, Fig.3.
- 4. Fit the TPS using the two M4 mounting screws and cover plate as shown Fig.4. Ensure that the sensor lever sits within the fork of the throttle lever and that the sensor is seated fully into the mounting bracket.



Pin 1 Signal
Pin 2 Ground
Pin 3 5V Ref.

Alpha Harness Colours
Purple/Blue
Blue
Green/Red



1 2 3

5. Fit the three pin socket from the wiring loom to the TPS.

6. Peel back the rubber cover on the connector on the wiri

- 6. Peel back the rubber cover on the connector on the wiring harness so that a voltmeter can be connected to the pins whilst still connected to the TPS.
- 7. Loosen the two screws holding the TPS to the bracket and rotate the TPS fully anticlockwise, then retighten the screws.
- 8. Start the engine and allow it to reach its normal operating temperature. Set the carburettor idle speed and balance.
- Connect the voltmeter to the following pins:
 Negative to pin 2 (blue wire) and positive to pin 3 (red/green wire). The reading should be 5 Volts (±0.1 Volt).
- 10. Slacken the two screws holding the TPS to the bracket so that it can be moved easily, but is not so loose that it will slip out of position.
- 11. Connect the voltmeter positive to pin 1 (purple/blue wire) and the negative to pin 2 (blue wire), and with the engine at idle turn the TPS clockwise until the voltage reaches 0.75V (±0.05V).
- 12. Tighten the screws and recheck the voltage.
- 13. Stop the engine and turn the ignition on. Hold the throttle fully open, the voltage should be at least 3.8V.
- 14. When the calibration is complete, disconnect the voltmeter and refit the rubber cover on the plug.



Fig.4



Fig.5

Fig.3



For further information, please contact: Webcon UK Limited

Dolphin Road, Sunbury, Middlesex, TW16 7HE, ENGLAND Tel: +44 (0) 1932 787100 Fax: +44 (0) 1932 782725 Internet: http://www.webcon.co.uk E-mail: sales@webcon.co.uk